




Instructions For the Fastime 24 Stopwatch: 10 lap memory, 2 Countdown Timers, Pacer, Alarm and Dual Time of Day Functions

Stopwatch mode: Select Chrono mode using the S3 button:

S2	S1	Event Timing:	Split Timing:
		S1 – Start S1 – Stop (time Out) S1 – Continue S1 – Stop S2 - Reset	Top display shows the lap number and cumulative time to last split. Bottom display shows lap time. Both displays freeze for 8 seconds when split. Timing continues in the background, then reverts to cumulative and lap running times S1 –Start S2 – Split (cumulative)
	S3 S4		S1 – Stop S2 - Reset

Memory Recall: Press **S3** anytime to recall memory.

Press **S1** to see each split time starting from the first split. Each display shows the split number, the lap time and cumulative time.

Press **S3** to scroll to chrono current running time.

N.B. Lap times are stored in memory until the stopwatch is restarted following reset.

Press **S3 MODE** button to move to Pacer display:

Press **S2** to set the pacer (from 40 to 160 per minute). Press **S1** to start/stop the pacer

The display shows the rate per minute on the top display and Time of day on the bottom display

Press **S3 MODE** button to move to Countdown Timer 1 (9hr 59m 59sec) display:

To set timer, Press and hold **S2** until digits flash. Press **S3** to choose digits to change. Press **S1** to change the digits. Press **S2** to exit setting.

To start/stop the timer press **S1**. **The timer will count down to 0 then count up. The alarm will sound whilst counting up. To silence this lightly press S1**

Press **S3 MODE** button to move to (normal) Time of Day/date display:

To set time of day and date, Press and hold **S2** until digits flash. Press **S3** to choose digits to change. Press **S1** to change the digits. Press **S2** to exit setting. Lightly press **S2** to switch between 12 – 24 hour setting

The same process applies to Time 2 – a second time of day option