

Fastime 14X instructions



Stopwatch operation Press **D** to select stopwatch mode.

Event Timing

- C** - Start
- C** - Stop (time Out)
- C** - Continue
- C** - Stop
- A** - Reset

Split Timing Top display shows the lap counter (000). Second row show the lap split time. Third row shows cumulative time. Fourth row shows the cumulative running time.

- C** - Start
- A** - Split (cumulative)
- A** - Split (up to 500 laps)
- C** - Stop
- A** - Reset

Recall Memory.

Press **B** anytime to recall memory. 1st display shows the 1st lap data taken.

Press **B** each split time for times starting from the last split. Each display shows the split number, lap time and cumulative time.

Continue to press **B** to get to STOP TIME, AVERAGE, BEST and SLOWEST lap data.

Press **B** to return to current running time. Press **C** to stop, press **A** to reset.

NOTES: If the lap counter shows a flashing '000' the memory is full and needs to be cleared

Recall Segmented Memory.

In Stopwatch Mode, if counter is running press **C** to stop. Press **A** to reset to 0.

Press **B** to enter recall. Lower row shows segmented time (MCH), middle and top rows show time of day/date.

Press **A** to select the MCH, then press **B** to recall the corresponding lap time record. Each display shows the split number, lap time and cumulative time.

Continue to press **B** to get to STOP TIME, AVERAGE, BEST and SLOWEST lap data.

Fastime 14x instructions continued

Clearing the Memory.

From Stopwatch Mode press **B** to enter recall.

Confirm the serial number after MCH is the one you wish to delete.

Press and hold **C** for 3 seconds to clear current MCH.

Press and hold **C** for 6 seconds to clear all data.



Pacer

Press **D** to move to Pacer display. Press **A** to set the pacer (from 10 to 320 per minute). Press **C** to start/stop the pacer.

How to set alarm, time and date

Press **D** to move to display.

Press and hold **B** to toggle alarm on/off.

Press and hold **A** until digits flash.

Press **A** to choose digits to change. Hold **C** for rapid digit change.

Press **B** to return to time of day display.

Timer

Press **D** to move to Dual Countdown Timer display. Top row is Timer 1, next row is Timer 2. The bottom row is the timer counter.

Press and hold **A** to set and select digits to change. Press **C** to change digits. Hold **C** for rapid digit change. Once set, press **C** to start the timer.

When Timer 1 approaches 0:00, it gives 4 beeps, and Timer 2 will start to countdown. When Timer 2 approaches 0:00 it gives 2 beeps, the timer counter will increase by 1 on the bottom row and Timer 1 will start to countdown.

To reset Timers to 0:00, press and hold **A**.