

Fastime 29 instructions



Stopwatch operation Press **D** to select stopwatch mode:

Event Timing

- C** - Start
- C** - Stop (time Out)
- C** - Continue
- C** - Stop
- A** - Reset

Split Timing

- Top display shows cumulative time to last split.
- Middle display shows previous split lap time.
- Bottom display shows the cumulative running time
- C** - Start
- A** - Split (cumulative)
- A** - Split
- C** - Stop
- A** - Reset

Memory Recall

Press **B** anytime to recall memory.

1 st display shows fastest lap number and time.

Press **B** again for slowest lap details

Press **B** each split time to show split times starting from the last split. Each display shows the split number, the lap time and cumulative time.

Press **D** to return to current running time

Timer

Press **D** to move to Repeating Countdown Timer..

To set the timer, press and hold **A** until digits flash. Press **A** to choose digits to change. Press **C** to change the digits. Hold **C** for rapid digit change. Press **D** to exit the setting.

Timer 2 starts when Timer 1 ends.

Pacer

Press **A** to set the pacer (from 10 to 320 per minute). Press **C** to start/stop the pacer. The display shows the pace per minute and the number of paces elapsed

Fastime 29 instructions continued

How to set time and date

Press **D** to select Date/Time of Day display.

To set time of day and date, press and hold **A** until digits flash.

Press **A** to choose digits to change.

Press **C** to change the digits.

Press **D** to exit setting

Set alarm

Press **D** to select Alarm display.

To set alarm time, press and hold **A** until digits flash.

Press **A** until you choose alarm.

Press **C** to change alarm from ON and OFF

Press **D** to exit mode.

