

Fastime 28 instructions



NB: Buttons A & D serve the same function

Stopwatch operation: Press **B** to start stopwatch. Press **B** to stop stopwatch. Press **C** to reset stopwatch to 0.00

<u>Event Timing</u>	<u>Split Timing</u>	<u>1,2 Fast Finish</u>
B - Start	B - Start	B - Start
B - Stop (time out)	C - Split (cumulative, internal timing continues)	C - Take and show the first finish time (internal timing continues)
B - Continue	C - Release	B - Stop 2 nd finish time
B - Stop	B - Stop	C - Show 2 nd finish time)
C - Reset	C - Reset	C - Reset

Display Time and Date and Turn Alarm on/off:

Press **A** button to move to Time of Day/date display. Hold **B** to display date and day.

Press **C** to display alarm time. Hold **C** and **B** to turn alarm on and off. Alarm icon displays when alarm is on.

Set Chime Per Hour: Press **A** to go to normal time. press **C** & **A** together. If the weekdays are showing the chime per hour is set.

How To Set Time and Date:

In time of day mode: Press **A** three times. The seconds digit will start flashing.

Press **C** to select the data: hours, minutes, seconds, date, month. A=AM, P=PM, H=24hr format. Press **B** to set the data (hold for quick scroll) Press **A** to confirm

How To Set The Alarm:

In time of day mode: Press **A** twice. The hour digit will start flashing. Press **B** to set the data (hold for quick scroll) Press **C** to select the data. Press **A** to return to time of day mode.

Snooze The Alarm: When the alarm sounds press **B** to snooze. It will sound again after 5 minutes. Press **C** to cancel the snooze.

Email: info@astopwatch.co.uk
Call: +44(0)7483 134 796

FASTIME