Fastime 11 instructions

Press **E** button for backlight

Stopwatch operation: Press **D** to start stopwatch. Press **D** to stop stopwatch. Press **C** to reset stopwatch to 0.00

Cumulative and Lap Split Timing

From normal time, press **A** until 'SW' appears above the display. Either 'Lap' or 'Cum' will flash.

Press **B** to choose lap or cumulative timing mode.
Press **D** to start.
Press **C** to take split time (internal timing continues).
Press **C** to release.
Press **D** to stop and **C** to reset.

1,2 Fast Finish

D - Start
C - Take the 1st finish time (internal timing continues)
D - Take 2nd finish time (see and record split 1 now)
C - Show 2nd finish time.
C- Reset.

Time of Day/Date Display

Press **A** button to move to Time of Day/date display.

To set time of day and date, Press and hold **A** until digits flash.

Press **B** to choose digits to change.

Press **D** to change the digits.

Press **A** to exit setting

Alarm:

Press **C** button to move to Alarm display.

To set alarm time, Press and hold **A** until digits flash

Press **B** to choose digits to change

Press **D** to change the digits

Press **A** to exit setting

Email: info@astopwatch.co.uk
Call: +44(0)7483 134 796

FASTIME

Fastime 11 instructions

Countdown Timers

Press **A** button to move to Repeating Countdown Timer display indicated by 'CD':

Press **B** to select from 3 options:

CR = Repeating Countdown
CC = Countdown to zero then count up
CS = Countdown then stop

To set timer, press and hold **A** until digits flash.

Press **B** to choose digits to change.

Press **D** to change the digits, hold **D** for rapid change. Press **A** to exit setting

Press **D** to start/stop the Timer

Email: info@astopwatch.co.uk
Call: +44(0)7483 134 796

FASTIME