

# Fastime 20 instructions



Stopwatch operation Press **D** to select stopwatch mode:

Event Timing

- C** - Start
- C** - Stop (time Out)
- C** - Continue
- C** - Stop
- A** - Reset

Split Timing TWO display options: Top display shows either cumulative or lap splits (Press **D** to choose). Bottom display shows cumulative running time.

- C** - Start
- A** - Split (cumulative)
- A** - Split (up to 100 laps)
- C** - Stop
- A** - Reset

Memory Recall

Press **B** anytime to recall memory.

Press **B** each split time for times starting from the last split. Each display shows the split number, lap time and cumulative time.

Press **C** to show the average lap time. Press **A** to show the fastest/slowest laps and lap times.

Press **D** to return to current running time. Press **C** to stop, press **A** to reset.

Timer

Press **D** to move to Repeating Countdown Timer..

To set the timer, press and hold **B** until digits flash. Press **A** to choose digits to change. Press **C** to change the digits. Hold **C** for rapid digit change. Press **B** to exit the setting.

To start/stop the timer press **C**. Display shows target time, countdown time and number of repeats.

Pacer

Press **A** to set the pacer (from 10 to 240 per minute). Press **C** to start/stop the pacer. The display shows the pace per minute and the number of paces elapsed

## Fastime 20 instructions continued

### How to set time and date

Press **D** to select Date/Time of Day display.

To set time of day and date, press and hold **B** until digits flash.

Press **A** to choose digits to change.

Press **C** to change the digits.

Press **B** to exit setting

### Set alarm

Press **D** to select Alarm display.

To set alarm time, press and hold **B** until digits flash.

Press **A** to choose digits to change.

Press **C** to change the digits. Press **B** to exit setting

