

Fastime 1 instructions



Stopwatch operation: Press **B** until you are at the stopwatch display. If the counter is already running press **C** to stop and **A** to reset to 0:00

<u>Event Timing</u>	<u>Split Timing</u>	<u>1,2 Finish</u>
C - Start	C - Start	C - Start
C - Stop (time Out)	A - Split (cumulative)	A - Stop
C - Continue	A - Release	C - Stop (1 st finish time)
C - Stop	C - Stop	A - Release (2 nd finish time)
A - Reset	A - Reset	A - Reset

Time, Date and Alarm Display:

Press **B** to switch between stopwatch and time of day display.

Hold **C** to display month, date and day.

Hold **A** to display alarm.

Hold **A** then press **C** to set alarm on or off.

How to set time and date:

Press and hold **B** to go to alarm mode. Then press **B** once more.

Press **C** to select digits.

Press **A** to change digits (seconds reset to 0).

Hold **A** for rapid digit change. Press **B** to return to time of day display.

Set alarm:

Press **B** and hold to enter set mode.

Press **C** to select the digits.

Press **A** to change the digits.

Press **B** to return to time of day.